

## Building a seine net

### Materials:

- Some fiberglass window screening; at least 2'x4'
- Two 30" wooden dowels (an old broom handle works fine) or small scrap lumber, about 4-6 inches longer than the screen is wide

### Tools:

- Carpenter's staplegun
- Scissors
- Hand saw

### Instructions:

1. Cut the screen to be about 2' wide by 4' long.
2. Cut the handles to be about 30" long, about 6 inches longer than the screen is wide.
3. Roll out the screen and place the handles on top, making sure that one of the ends is even with the bottom of the screen.
4. Wrap the screen around the handle, just so that the screen is on top.
5. Staple the screen to the handles, starting just off the bottom of each stick and working to the top of the screen, putting in a staple every couple of inches.
6. Roll the screen around the sticks working both sides at the same time to carry or store the net.

